


Flam[®]



Heating Technology

**One Stage
Gas Burner**



Model:

SC 1.1 GS
SC 1.2 GS
SC 2.1 GS
SC 2.2 GS
SC 3.1 GS

Body Type:

Gama

Language:

English

INDEX

BURNER SPECIFICATIONS	3
CERTIFICATES	4
BODY TYPES	5
PRODUCT ENCODE.....	6
DECLARATION OF CONFORMITY	7
WARNING NOTES.....	8
ELECTRICAL WARNING SIGNS	11
PRESSURE DROPS	12
FLAME LENGHT AND DIAMETERS (GAS)	13
CAPACITY CURVES.....	14
BURNER DATA TABLE	17
BURNER DIMENSION TABLE	18
MOUNTING	19
OPERATIONAL EXPLANATION	20
EXPLODED PICTURE	21
NUMBERED EXPLODED PICTURE	22
IGNITION ELECTRODE TURBULATOR AND ITS POSITION	23
GAS AND AIR PRESSURE SWICH	24
GAS VALVE CONNECTION	25
MAINTENANCE	26
COMMISSIONING PROCEDURE.....	27
PACKING	28
GAS VALVE - DUNGS MB DLE	29

BURNER SPECIFICATIONS

EASY SETUP

Flam burners are easy to set up with the prototype structure. It can be used with different options in ovens, dryers, generators, water and steam boilers. Horizontal and upwards can be set up.

FUELS

It can be used with artificial fuels like gas (G), motor (L), fuel oil (H) and other biogas, LPG.

DESIGN

Flam burners have a modern design, maintenance and easy serviceability for technical service is provided.

WORKING PRINCIPLES

Our burners have single and double stage and modulation options. Modulation has pneumatic and mechanical and electronics options. Modulation with the PID controller can be implemented. Our modulation ratio can be up to 1/5 of a 1/10.

BURNER OPERATION OPTIONS

In our fully modulated burners, we add PID control. You can also choose O₂ trim, inverter, and low NO_x options.

ENVIRONMENT-FRIENDLY TECHNOLOGY

Flam burner has reduced No_x values to European standards with its advanced technological structure and continues to work on this subject.

WORLDWIDE TECHNICAL SERVICE

Our service team can serve you in every corner of the world. Dynamic and experienced gives you the promise of the best service.

CUSTOMIZE SOLUTION

Our team can offer you customize solution for your systems. Special design and calculation is our pleasure.

CE



Gas Burner CE Design Module Production Module CE, ISO 9001: 2008 Quality Management Certificate and continue with the sales market.

CE Design Module, CE Production Module, ISO 9001: 2008 Quality Management Certificates and CE Certificates can be accepted for the Motor-Gas Double Fuel Burners.

BODY TYPES

We use up to 17,800 kW of our **Alfa** type body for gas, oil and gas /oil fuels.

We use **Beta** body up to 17.800 kW in heavy oil and gas / heavy oil fuels.

We use up to 11,000 kW of our **Gama** burners in our gas-fired burners.







We use our **Delta** body in our Duoblock models from 500 kW to 7,800 kW in gas, oil, heavy oil and dual fuel.

We use our Epsilon body in our Doublock models from 10,500 kW to 35,000 kW in gas, oil, heavy oil and dual fuels.

We use our **Pi** model from 180 kW to 500 kW in our custom ram burners.


Our control panels vary according to body size and are simple to use.

Our service network covers all of Spain. We can send technical support to every part of the world.



PRODUCT ENCODE

SC. 12-2-G-M-(P)-Beta



BODY SIZE: 0-1-2-3-5-8-10-12-14-16-18-20-22

BODY CAPACITY: 1-2-3

FUEL TYPE:

G-GAS

L-LIGHT OIL

H-HEAVY OIL

GL-GAS/LIGHT OIL

GH-GAS/HEAVY OIL

OPERATION MODE:

S-SINGLE STAGE

Z-TWO STAGE

M-MODULATING

WORKING OPTIONS:

(P)-PNEUMATIC MODULATION

(M)- MECHANIC MODULATION

(E)-ELECTRONIC MODULATION

(I)-INVERTER (Variable-Frequency Controller)

(LN)- LOW NO_x

(O2) OXYGEN TRIM

BODY TYPE: STATED IN THE PREVIOUS PAGE.

DECLARATION OF CONFORMITY

Before using the burner for the first time, please ensure that the product is an integral part of this manual, which is supplied with the burner.

Read USER'S WARNING FOR USING BURNER" section carefully. Burner and system operations must only perform by authorized personnel.

- Be sure to read the operating manual carefully before starting to operate or repair the burner.
 - The power supply of the system must be disconnected before the repair on the burner
- We hereby declare that the suitability of our "CE" marking SC series products is under our sole responsibility. starts.
- It is possible to cause dangerous accidents if the instructions are not followed strictly and the work is not carried out properly.

Description

Gas or dual-fuel blow-domestic and industrial burners on the minimum regulations that apply European Directives:

- 90/396/EEC
- 92/42/EEC
- 89/336/EEC
- 73/23/EEC
- 98/37 EEC

and the European Standards subject to the design and testing:

- EN 676 (gas ve çift yakıtlı, gas tarafı)
- EN 60335-1, 2003
- EN 50165: 1997 + A1:2001 + A2:2002
- EN 55014 -1 (1994) and -2 (1997)

The control according to Directive 90/396 / EEC Gas Devices;
CE2159 - Made by S & Q MART.

WARNING NOTES

USE THE BURNER SAFELY USER WARNING NOTES

1. General Information

This product must only be used in accordance with its intended use by applying the specified installation and commissioning protocols. Other than intended use, death, injury and serious burning may occur.

Before using the burner for the first time, please read carefully the “USER WARNING NOTES FOR USE OF BURNER SAFETY” section of this manual, supplied with the burner as an integral part of the product. Operation of the burner and the system must only be carried out by authorized personnel. The power supply of the system must be disconnected before repair on the burner starts.

It is possible to make dangerous accidents that the instructions are not followed carefully and the workings are not carried out properly.

The lifetime of the burner is 10 years

2. Preface

These warning notes have been prepared with the aim of ensuring the healthy use of the components of the heating systems for civilian use and hot water production.

These notes illustrate how equipment with adequate reliability can be acted on with the purpose of avoiding damage caused by incorrect or faulty installations or improper and unreasonable use.

In addition, the warning notes in this manual are technically prepared on a level that makes users understand and is aimed at having users knowledgeable about safety issues.

The manufacturer is not liable for damages caused by errors in the installation or use of the product not in compliance with the manufacturer’s instructions

3. General Warning Notes

The user manual is a special and necessary part of the product and must be supplied to the user. Read the warnings in the manual carefully as it contains

important information on safe use, maintenance, and installation. Keep the guide where you can find it when you need it.

Materials must be installed by qualified technicians according to current standards and manufacturer’s instructions. By “qualified technicians” it is meant those who are experts on domestic heating and hot water production system components, and especially those authorized by the manufacturer. Incorrect installation can harm people, animals, and equipment. The manufacturer is not responsible for such damages.

When the package is opened, check that all parts are present and undamaged. If in doubt, do not use materials and return your dealer. The packaging materials (wooden cage chests, plastic bags, foam, etc ...) Keep out of the reach of children. These materials must be collected and disposed of appropriately so as not to create environmental pollution.

Before any maintenance or cleaning, turn off the power of your device using the system switch at the mains supply or switch off all the appliances.

If the system is faulty or if your device is not working properly, turn off your device, do not attempt to repair it or do not interfere with it. In such cases, contact the authorized service center only. Any material repairs must be made by Flamtec Authorized Services using original spare parts.

Failure to act as above may jeopardize the safety of the equipment. Periodic maintenance must be carried out by authorized services in accordance with the operating instructions to ensure that the equipment operates correctly and efficiently.

If the hardware is sold or shipped to another user, or if the owner of the device leaves or surrenders; ensure that the operating instructions are always on the side of the unit. This way the new owner and/or installer can benefit from the guide.

Only original materials should be used for all equipment of the device, including optional materials or kits (including electrical equipment).

4. Burners

This device should only be used in boilers for applications that are connected to hot water boilers, ovens or other similar equipment and are not exposed to atmospheric agents (rain, dust, etc.). Other forms of use are inadequate and, therefore, it is dangerous.

The burner should be installed in the appropriate locations according to the regulations in force and in all cases where adequate ventilation is available to ensure proper combustion.

Do not reduce or cover the ventilation opening of the burner or the boiler room where the boiler is installed and the burner air intake grill opening, as hazardous oxide mixtures and explosive gas forms may form.

Before connecting the burner, check the information on the system feed (electrical, gas, motor, or other fuel) related information on the label on the front.

Do not touch the hot parts of the burner. Usually in the areas near to the flame and the fuel preheating system components are hot during operation of the device and remain hot for some time.

If the burner is no longer used, the following operations must be carried out by authorized technicians;

- a) Disconnecting the power supply line from the main switch, disconnecting the power supply,
- b) Closing the fuel supply using the shutoff valve and removing the valve release lever,
- c) Picking up parts of potentially hazardous parts,

5. Special Alerts

Check that the connection of the burner to the heat generator is secure, as it will occur in the flame combustion chamber. The following procedures are required to be tested by authorized technicians at least once a year and once before commissioning the burner;

- a) Adjustment of burner fuel level, adjustment of the capacity of the heat generator.
- b) Adjustment of the combustion air flow at least to ensure combustion efficiency of the burner at the minimum air flow rate declared by the current

regulations.

c) Check that NO_x and unburned gases causing air pollution do not exceed the permissible limit values according to the current legislation.

d) To check that the safety devices and control devices are working properly.

e) Checking the condition of the duct where the combustion products are discharged.

f) After the setting operations have been carried out, the mechanical safety locks of the adjusting devices must be made,

g) To check that the burner operating and maintenance manual is in the boiler room.

If the burner is continuously failing, do not try to reset it more than twice. Call your nearest authorized service agent to resolve the problem.

According to the regulations in force, the operation and maintenance of the equipment should only be carried out by authorized services.

6. Electrical Connection

The equipment is only electrically safe if properly connected to the appropriate earthing line according to current electrical safety legislation.

It is necessary to check that the necessary safety requirements have been fulfilled. If you are in doubt, have a certified electrician check the system.

Because the manufacturer is not responsible for damage caused by poor grounding connection.

The suitability of the electrical circuits for maximum loads of the equipment must be checked by authorized services. Have the certified electrician check that proper wiring is done according to the maximum power drawn by the burner as shown on the technical labels, especially if the cable diameters are sufficient for the power drawn.

According to the current safety legislation, it is necessary to use a polarity switch to connect the main power supply.

The burner power supply must have neutral grounding. If the ionization current is controlled from an ungrounded neutral, a connection must be made between the terminal 2 (neutral) and ground

WARNING NOTES

for the RC circuit.

Use of any electric parts; It is subject to compliance with the basic principles of electric safety rules reported below;

-Do not touch equipment with wet or damp parts of your body.

-Don't take the electric cables.

-Do not leave your device in atmospheric (rain, sun, etc.) environments unless proper storage characteristics have been specified.

-Do not allow unauthorized persons and children to use.

-The mains power cables cannot be changed by the user. If the cables are damaged, disconnect the equipment from the mains and call only authorized service personnel to replace the cables.

-If you decide not to use your device for a while, it is recommended that you disconnect all electrical equipment (pump, burner, etc.) from the electrical connection.

7. General Warning Notes on Gas, Motor or Other Use

The burner installation must be carried out by authorized technicians in accordance with the existing laws. Incorrect installation may harm human beings, animals, and other persons, in which case the manufacturer is not responsible for this damage.

Before installing the burner, it is recommended to clean the dirt inside the fuel supply line piping, which may prevent the system from operating properly.

For the first commissioning of the burner, have the following checks carried out by authorized services:

If you have decided not to use the burner for a while, close the valves or valves on the fuel line.

Special warning notes when using gas:

Authorized technical service:

- check the compliance of the pipeline and gas lines with the applicable laws and regulations,

- check that the gas lines are leakproof.

-Don't use gas pipes for grounding electrical appliances.

--Do not leave your device in operation when you are not using it and always keep the gas valve closed.

- When the user goes away for a while, turn off the main valve that brings the burner gas.

If you get the gas smell:

- never use a power switch, telephone or any other device that may spark;

- open the doors and windows to provide airflow to clear the air of the room;

- close the gas valves;

- ask for technical assistance.

- Do not close the ventilation openings of the spaces where gas-fired devices are located, otherwise dangerous situations may occur due to the formation of the toxic and explosive mixture.


ELECTRICAL WARNING SIGNS




CAUTION VOLTAGE



ENERGY CLOSE WITHOUT
OPENING THE SHUTTER








DAMPER ADJUSTMENT
(OXYGEN ADJUSTMENT)



ENGINE ROTATION


PRESSURE DROPS




————— Gas Pressure Drop in barrel and gas train
————— Gas Pressure Drop in barrel

FLAME LENGHT AND DIAMETERS (GAS)



GAS - FLAME HEIGHT





GAS - FLAME DIAMETER




CAPACITY CURVES



CAPACITY CURVES



CAPACITY CURVES




BURNER DATA TABLE



TYPE	CAPACITY						Power Supply	Motor kW	Gas Input Pressure (mbar)
	kW		kcal/h		m3/h				
	min	max	min	max	min	max			
SC 1.1 GS	18	120	15.480	103.200	1,88	12,51	1N -50 Hz 230V	0,15	21-300
SC 1.2 GS	50	180	43.000	154.800	5,21	18,76	1N -50 Hz 230V	0,15	21-300
SC 2.1 GS	80	280	68.800	240.800	8,34	29,19	1N -50 Hz 230V	0,25	21-300
SC 2.2 GS	100	360	86.000	309.600	10,42	37,53	1N -50 Hz 230V	0,25	21-300
SC 3.1 GS	110	500	94.600	430.000	11,47	52,12	1N -50 Hz 230V	0,37	21-300

BURNER DIMENSION TABLE



	A1	A2	B1	B2	ØC	C1	C2	ØC3	ØE	ØF	L1	L2	L
SC 1.1 GS	225	275	250	180	90	110	104	M6	90	90	78	180	625
SC 1.2 GS	225	275	250	180	114	130	125	M8	120	114	110	160	700
SC 2.1 GS	250	300	290	190	114	130	125	M10	120	114	110	160	790
SC 2.2 GS	250	300	290	190	140	155	142	M12	155	140	110	330	880
SC 3.1 GS	310	380	320	250	140	155	142	M12	155	140	130	330	1060

MOUNTING



OPERATIONAL EXPLANATION

Phases

PAUSE: Burner air shutter is open is fixed in position by hand. There is no gas in gas train.

PRE-SWEEPING: The burner fan motor starts to operate following the command from the boiler oven thermostat or pressure switch. There is no gas passage in this phase. Only the fan is running.

FORMING FLAME: Fan works. Gas regulator is adjusted to the gas inlet pressure. Ignition transformer works and gas valve opens.

Operation Instructions

By switching off the main switch, if the thermostats are closed, it will reach the voltage box and after a short time, the burner will switch on according to the ignition program. The fan motor will start and function and will pre-sweep the combustion chamber. Then, the control box drives the energy to the ignition transformer and after a while, the safety valve and the working valve are opened. When the flame is formed in this way, the flame detector detects flame. The control box allows the ignition program to continue and pass the ignition phase. If a flame fault occurs, the control box performs a "safe stop" (blocking) function after 2 seconds after opening the gas valves. When "Safe Close" occurs, gas valves (safety and operation valves) are instantly turned off. Press the key on the control panel to remove the control box from its safe position. Press the maximum 3 times.

NOTE: The burner 2 has a switch to pass from 1st stage of step manual control.

- 1) Check that there is water in the boiler and open the gate valves of the system.
- 2) Be absolutely sure that the combustion products can easily come out (the boiler outlet and the boiler are open).
- 3) Check that the current, voltage and power values to be connected are appropriate for the burner required values and the electrical supply voltages of the electrical connections (motor and mains). The electrical connections will be made according to our electrical cycle. Turn off the 1st stage / switch in the burner to prevent it from

moving to the second flame stage.

4) (depending on the boiler type) If the refractory lining of the combustion chamber, according to the instructions supplied by the boiler manufacturer burner head circumference must be lined with refractory material.


5) The electrical supply of the burner must be made according to the electrical connections arranged on the burner for the input voltages and as shown in our circuit diagram.

6) Fuel line piping must be done according to the schematic.

7) Make sure that the nozzle with the proper characteristics is fitted. Replace with the appropriate one if necessary. In no case should the fuel flow in the furnace be greater than the maximum permissible output for the burner and the maximum required for the furnace. The nozzle spray angle should be sufficient to avoid problems (vibrating flame, dirty and burning head contamination, improper commissioning, etc.).

8) Make sure that the burner head is inserted into the combustion chamber according to the instructions of the boiler manufacturer.


NUMBERED EXPLODED PICTURE



PARÇA NO	PARÇA ADI	ADET
1	BURNER BODY	1
2	CONTROL BUTTONS	1
3	BUTTONS PANEL	1
4	ELECTRIC PANEL	1
5	ELECTRIC PANEL BASE	1
6	BURNER AIR DAMPER	1
7	SIEMENS LME 22 B.M.S	1
8	ELECTRIC PANEL COVER	1
9	SOCKET	1
10	AIR PRESOSTAT	1
11	2x7,5 kw IGNITION TRANSFORMER	1
12	SIEMENS ACTUATOR	1
13	BARREL HINGE SHAFT	1
14	BARREL HINGE FLANGE	1
15	COMBUSTION HEAD SHAFT	1
16	BARREL	1
17	SLIDE BOILER FLANGE	1
18	ASBESTOS GASKET	1
19	GAS HIVE	1
20	OCTOPUS	1
21	IGNITION ELECTRODE	1
22	GAS NOZZLE	6
23	DIFUSER	1
24	COMBUSTION HEAD	1
25	IONIZATION ELECTRODE	1
26	FLAM GAS VALVE	1
27	MECHANIC CAM GROUP	1
28	AIR FLAP PLATE SHAFT & DAMPER	1
29	MULTIBLOCK GAS VALVE	1
30	MIN GAS PRESSURE PRESOSTAT	1
31	MAX GAS PRESSURE PRESOSTAT	1
32	BURNER FAN MOTOR	1
33	FAN MOTOR FLANGE	1
34	BURNER FAN	1
35	OBSERVATION GLASS	1

IGNITION ELECTRODE TURBULATOR AND ITS POSITION

The position of the ignition electrode and the turbulators is important to ensure proper combustion. The distance of the ignition electrode to the pilot gas bubble and the distance between the turbulator and the bushes must be specified.



The specified distance is valid for single electrode models. For models with dual ignition electrodes, the distance between the two electrodes should be 3 mm. The distance between each of the electrodes should not be less than 4 mm.

GAS AND AIR PRESSURE SWITCH



1. Minimum Gas Pressure Switch

Dungs GW150 A5 is used in our burner as standard minimum pressure switch. It closes the burner when the gas comes under a certain pressure. For every installation, it must be set by commissioner.

Operation

Please make the adjustment of the air pressure switch after done with all the electrical and insfructural settings. Remove the cover with a screw. When burner works, turn to left the scale untill burner stops. When burner stops, turn to right 0,2 point as a set up point. Close the cover again!

2. Maximum Gas Pressure Switch,

Dungs GW 500 A2 is used in our berner as maximum pressure switch. It ensures that the burner

Operation

After the adjusment of the minimum gas pressure, start bunerer again. When te burner works, open the cover of maximum gas pressure switch with a screw. Turn to left the scale untill the burner stops. When it stops, turn to the right 0,2 points as a set up point. Close the cover.

3. Air Pressure Switch

Dungs LGW3 A2 is used in our burners as our standards. It closes the burner when the air is not enough.

Operation

Adjust the air pressure switch after you have made all other burner settings. When the burner is

operating in the first stage, increase the adjustment pressure by turning the respective knob clockwise until the burner stops. Then turn the knob from the set point to about 20% counter-clockwise and run the burner again to check the accuracy.

If the burner stalls again, turn the knob a little further, as opposed to clockwise. Caution: As a rule, the air pressure limits the CO in the flue gas to be less than 1% (10,000 ppm). To check this, connect a gas analyzer to the flue gas, slowly turn off the fan suction (eg with a carton piece) and see that the burner stopped before CO 1% in the flue gas.


If the air pressure switch is connected to two pipes, it can also work as a differential. If the negative pressure in the combustion chamber during pre-sweeping prevents the air pressure switch from entering the circuit, it can be done by putting a second conduit between the switching air pressure and the suction of the fan. In this way, the air pressure switch works like a differential switch.

Caution: Differential operation of the air pressure switch is only allowed in industrial applications and where the air pressure switch of the rules permits only the fan to operate without any CO limit. will close




GAS VALVE CONNECTION

MULTI-BURNER, PRESSURE GAS PIPELINE CONNECTION DIAGRAM IN THE INTERMEDIATE LEVEL



- 1) Measuring and dropping unit
 - 2) Cutting valve
 - 3) Filter
 - 4) Reducing
 - 5) Counter
 - 6) Emergency shut-off valve (installed outside the building)
 - 7) Ball valve
 - 8) Filter
 - 9) Final reducer or stabilizer
 - 10) Vibration receiver
 - 11) Double flange
- D = distance between pressure stabilizer and flange (approx. 1.5 - 2 m)

A BURNER'S MEDIUM LEVEL PRESSURIZED GAS PIPE HALT TO CONNECTION DIAGRAM



- 1) Measuring and dropping unit
- 2) Cutting valve
- 3) Filter
- 4) Reducing
- 5) Counter
- 6) Cage wire flame holder
- 7) Automatic opening overpressure relief valve (open outdoors at an appropriate place it must discharge)
- 8) Emergency shut-off valve (outside the building)
- 9) Ball valve
- 10) Vibration receiver
- 11) A flange pair

MAINTENANCE

- The electrical connection should be cut off first and the gas completely closed.
- The burner does not require special maintenance. However, it is a good practice to periodically check that the gas filter is clean and the ignition electrode is intact.
- In addition, it is also necessary to check the occurrence of electrode sparking between the ignition electrode and the disk.
- The combustion head may need to be cleaned.
- Center the electrodes (ignition and ionization) precisely so that they do not touch the ground when they are put back into position and do not trip the burner.
- Most of the braking equipment can be controlled by opening the hinge.
- It is necessary to remove the mixing unit to check the head.
- The fan and turbulator should be cleaned.
- O₂, CO, and CO₂ values should be checked once a month.
- If boiler connection gaskets are damaged, they must be replaced.
- Regular maintenance of the boiler should be done.
- Smoke pipes should be cleaned once a month.
- Chimney cleaning should be done during the season passes.
- Run the boiler for summer periods, several times a month for 5 minutes, to prevent the pumps from being crushed.
- Check the air flow in the boiler room.
- Prevent the boiler chamber from getting wet. Never contact the burner with water it must not.
- Do not add water to the boiler when the boiler is hot.

COMMISSIONING PROCEDURE

The burners purchased from our company are important for the first time that the technical manager of the company who engages in the commissioning, purchasing or mechanical and electrical installation work is present during the commissioning of the burner.


The controls and works on the table below must be completed so that your burner, who has been purchased, can be activated without any problems at a time. The first start-up of our burners is done free of charge by our company or authorized service providers in Turkey.

Our company and its authorized service are not responsible for the fact that the burner can not be commissioned for the first time due to the items mentioned in the procedure or due to problems caused by the statements. The second round of commissioning visit to the facility and the first start-up activity will be carried out for the cost. The following instructions must be completed by you or your customers. When our authorized service technician arrives for the second time to your installation, you will be charged 50 Euros + VAT for each burner, 30 Euros / 100 km for the return journey and 30 Euros / 100 km for the return journey. Commissioning details to be completed before burner commissioning.

- 1 - Mechanical installation of the burner head must be done correctly.
- 2 - The burner must have provided the necessary nosepiece to the boiler of the combustion head. (Min 7 - 10 cm.) (If the burner does not fit properly in the boiler shell, it may start inside the burner door and damage the boiler cover.)
- 3 - There must be thermostats on the boiler to provide boiler water temperature and one safety and one operation control to ensure safety of the burner.
- 4 - The electrical and mechanical connections of the safety and operating equipment on the device to be operated by the burner must be made to the system.
- 5 - The air of the installation should be taken by filling the system with water.
- 6 - The closed expansion tank pressure connected to the system should be adjusted according to the operating pressure of the system.
- 7 - The circulation pumps must be in operation.
- 8 - Electrical installation must be completed (Temperature sensor-Thermostat-to-burner main supply cables)
- 9 - Fuel supply has been provided and the necessary connections to the burner have been made correctly.
- 10 - If there is a gas in the burner, there should be a manometer.
- 11 - Required legal permissions have been obtained (Gas opening certificate etc.)
- 12 - If the burner is proportional controlled, the temperature sensor or pressure transmitter shall be provided and mechanical and electrical connections shall be made to the burner to provide proportional operation of the burner.
- 13-No water leakage is required in the installation.

We will be sent to our customers as a " Request Form " together with our burners. By filling out the form and sending it to us by fax or e-mail it will be delayed and problems will be prevented. It is important to inform your customers in this regard.

PACKING



	Lenght(a)	Width(b)	Height(c)	Weight
SC 1.1 GS	66 cm	51 cm	47 cm	35 kg
SC 1.2 GS	73 cm	51 cm	47 cm	35 kg
SC 2.1 GS	81 cm	58 cm	51 cm	40 kg
SC 2.2 GS	90 cm	58 cm	51 cm	40 kg
SC 3.1 GS	111 cm	71 cm	71 cm	45 kg

Untill 2.2 GS We deliver in cartoon box. Others in wooden or plastic box.

GAS VALVE - DUNGS MB DLE

Technical description

The DUNGS GasMultiBloc® integrates filter, regulator, valves and pressure switches in one compact fitting.

- Dirt trap: Fine mesh-sieve
- One regulator and two valves: B01
- Two valves are fast opening
- One valve is fast opening and one valve is slow opening
- Solenoid valves up to 360 mbar (36 kPa) as per DIN EN 161 Class A Group 2
- Sensitive setting of output pressure by proportional regulator as per DIN EN 88 Class A Group 2
- High flow rates with low pressure drop
- DC solenoid drive interference degree N
- Main volume restrictor at valve V2
- Hydraulic opening delay
- Flange connections with pipe threads as per ISO 7/1
- Simple mounting, compact, light- weight

The modular system permits individual solutions by using external ignition gas tap in connection with separately controlled valves, by adding a valve proving system, mini/maxi pressure switches, pressure limiters, limit switch V2.

Application

The modular system permits individual solutions in gas safety and regulator engineering. Suitable for gases of families 1, 2, 3 and other neutral gaseous media.

Measuring/ignition gas connection

Burner pressure monitor pBr

Connection downstream of valve V2, pressure switch A2 mountable on adapter laterally

Voltage / frequency

50-60 Hz 220-230 V AC - 15% + 10%

Other preferred voltages: 240 VAC, 110-120 VAC, 48 VDC, 24-28 VDC

Electrical connection

Plug connection as per DIN EN 175301-803 for valves and pressure switches

Rating/power consumption: Refer on page 4

Switch-on duration: 100%

Degree of protection: IP 54 as per IEC 529 (EN 60529)

Radio interference: Interference degree Materials of

	Valve V2 design		Main volume restrictor
MB	fast closing	fast opening	without
MB-D	fast closing	fast opening	with
MB-DLE	fast closing	slow opening	with
MB-LE	fast closing	slow opening	without

gas-conveying parts

Housing:

Aluminium die casting

Diaphragms, seals:

NBR basis, Silopren (silicone rubber)

Solenoid drive:

Steel, brass, aluminium

Installation position

Solenoid vertically upright or lying horizontally as well as its intermediate positions

Closed position signal contact

Closed position signal contact, type K01/1 (DIN-tested), mountable on V2


GAS VALVE - DUNGS MB DLE

Equipment variants GasMultiBloc®...B01 Single-stage function	405 B01	407 B01	410 B01	412 B01	
MB	•	•	•	•	
MB-D	•	•	•	•	
MB-DLE	•	•	•	•	
MB-LE	•	•	•	•	
Microfilter with sieve	•	•	•	•	
Gas pressure switch downstream of filter	•	•	•	•	
downstream of valve V2 on adapter laterally	•	•	•	•	
downstream of valve V2 on flange with adapter	•	•	•	•	
Pressure regulator	•	•	•	•	
Valve V1, double seat	•	•	•	•	
Valve V2, single seat	•	–	•	–	
Valve V2, double seat	–	•	–	•	
Valves controlled together	•	•	•	•	S 20, S 50
Valves controlled separately	•	•	•	•	S 22, S 52
Flange Rp 1/2	•	•	–	–	
Rp 3/4	•	•	•	•	
Rp 1	–	–	•	•	
Rp 1 1/4	–	–	•	•	

• = possible
 (•) = on request
 - = not pos

MB-...B01 version

- V1 = Valve 1
- V2 = Valve 2
- 3 = Dirt trap
- 4 = Pressure switch
- 5 = Regulator




Mounting of VPS 504 valve proving system possible
 Mounting of K01/1 closed position signal contact

Typ	Rp	Opening time	Dimensions [mm]								Weight [kg]
			a	b	c	d	e	f	g	h	
MB-D 405 B.../407 B...	Rp 1/2	< 1 s	110	151	40	46	100	185	74	115	2,5
MB-DLE 405 B.../407 B...	Rp 3/4	< 20 s	110	151	40	46	140	185	74	115	2,6
MB-D 410 B.../412 B...	Rp 1	< 1 s	140	185	40	55	125	245	90	135	4,9
MB-DLE 410 B.../412 B...	Rp 1 1/4	< 20 s	140	185	40	55	160	245	90	135	5,0

GAS VALVE - DUNGS MB DLE

Electrical connection





Rating / power consumption

[VA] ~(AC) 230 V; +20 °C:

MB 405/407 S 20	32
MB 405/407 S 50	36
MB 405/407 S 22	46
MB 405/407 S 52	46
MB 410/412 S 20	55
MB 410/412 S 50	55
MB 410/412 S 22	96
MB 410/412 S 52	96

Pressure taps



1,3,4,5 G 1/8 screw plug
2 Test nipple

Setting the pressure regulator

1. Open protective cover 1.
2. Set pressure controller to the desired output pressure p_a using the screwdriver no. 3, Fig. 1. Possible output pressure ranges: 4-20 mbar or 4-50 bar. Pressure measurement at pressure taps no. 4.

Lead seal

figure 2






figure 1

Lead seal eye 2 in 1.5 mm dia. sealing cover. Lead seal eye 3 in 1.5 mm capstan headed screw.

After setting the required pressure setpoint:

1. Close protective cover 1.
2. Route wire through 2 and 3, Fig. 2
3. Press lead around wire ends, keep wire loop

GAS VALVE - DUNGS MB DLE



short.



Setting the bypass throttle MB...-B07

1. Remove setting cap 1 from the bypass throttle (see Fig. 1).
2. Set bypass throttle using screwdriver no. 3 (see Fig. 3).

Rotate clockwise = reduce ignition gas volume.
 maximum ignition gas volume is specified via outlet pressure p_a of pressure regulator part (see characteristic $\Delta p/V$ for V3).

3. Protect setting using varnish. Rescrew setting cap 1.

Main flow setting only possible at V2.



Main flow setting on delivery: (open) max. Secure setting by applying varnish. Setting of MB-... and MB-LE... not possible.

MB-DLE ... B07 MB-LE ... B07

Rapid stroke adjustment Vstart Factory setting MB-DLE ... B01, MB-LE ... B01: Rapid stroke not adjusted


1. Unscrew the adjustment cap E from the hydraulic

brake.

2. Invert the adjustment cap and use as a tool.

3. Turn anti-clockwise = increase rapid stroke (+)
 Replacing hydraulic brake unit or adjustment plate

1. Switch off firing system.



2. Remove locking varnish from countersunk screw A.

3. Unscrew countersunk screw A.

4. Unscrew socket head screw B.


5. Raise adjustment plate C or hydraulic brake D.

6. Exchange adjustment plate C or hydraulic

D

GAS VALVE - DUNGS MB DLE

7. Screw in countersunk and socket head screw. Only tighten socket head screw so that hydraulic brake can just be turned.
8. Coat countersunk screw A with locking varnish.
9. Leakage test: Pressure tap at seal plug 4



screws crosswise. Make sure that the device is mounted free of strain! Do not allow any direct contact between the GasMultiBloc and hardened masonry, concrete walls or floors. Always adjust nominal output or pressure setpoints on the gas pressure regulator and performance-specific throttling using the V2.

Always use new seals after dismounting and mounting parts. Pipeline leakage test: close ball valve upstream of GasMultiBloc. On completion of work on the GasMultiBloc, perform a leakage and function test. Never perform work if gas pressure or power is applied. No naked flame. Observe public regulations.

If these instructions are not heeded, the result may be personal injury or damage to property

$p_{max.} = 360 \text{ mbar}$.

10. Perform functional test.
11. Switch on firing system.



MB- ... B07 Filter check

Check the filter at least once a year!

Change the filter, if Δp between pressure connection

2 and 3 $> 10 \text{ mbar}$. Dismount device, see page 3.

Replace O-ring and filter. Change the filter, if Δp



between pressure connection 2 and 3 is twice as high compared to the last check.

Work on the GasMultiBloc may only be performed by specialist staff. Protect flange surfaces. Tighten



Selkoc
Isıtma & Soğutma Otomasyon San. Tic. Ltd. Şti.

Selkoc Isıtma ve Soğutma Otomasyon
San. Tic. Ltd.
Şti. İsmetpaşa Mah. Hisar Sok. Üstün İş
Merkezi.
No: 20/53 Tel: +90 212 501 48 54
Fax: +90 212 501 48 57
info@selkoc.com.tr
www.selkoc.com.tr